

Firemen intercom system.

Panel

- a. Inspect the condition of the panel and its housing.
- b. Ensure that the panel is in a normal-ready condition.
- c. Visually inspect condition of components, resistors wires, zone cards, bulbs etc. Repair / replace as necessary.
- d. Inspect condition of battery charger. Repair / replace as necessary.

Battery

- a. Inspect the condition of the battery and its terminal. Repair / replace as necessary.
- b. Inspect voltage and ammeter reading. Repair / replace as necessary.
- c. Inspect and test all battery charger units. Repair / replace as necessary.

Automatic Control

- a. Inspect and test the control wiring and circuitry. Random test of the call, talk and fault mode.
- b. Inspect the correct operation of the master and remote handset. Establish conference calls on auto and manual mode. Test disconnect call on auto and manual mode.
- c. Inspect and test the correct operation of remote status panel.

Electrical

- a. Check the operation of the emergency change over in case of power failure. Repair / replace as necessary.
- b. Check the wiring connection terminals. Repair / replace as necessary.
- c. Check the condition of the conduits, wires and supports. Repair / replace as necessary.

Handsets

- a. Inspect the condition of the master hand set. Repair / replace as necessary.
- b. Inspect the condition of the remote handset box. Repair / replace as necessary.
- c. Inspect any missing, damaged or deteriorated parts on the remote handset and accessories. Repair / replace as necessary.

General

- a. Keep remote handsets clean and tidy.
- b. Keep access to panel free from obstructions.